



# ACCESSORIES

Part#	Description	Weight
2000	ULTRA-Jack®	32.00
2002	ULTRA Brace	9.00
2004	ULTRA Work Bench	15.00
2008	ULTRA Pole Anchor	6.00
2009	ULTRA Pole Base	1.00
2013	ULTRA / ALL PRO 6' Pole Connector	16.00
3000	ALL PRO Net	10.00



## [1] ULTRA-Jack® (2000) ↘

- Walk plank fastening system provided
- Adjustable platform 14" to 24"
- Highest climbing rate per stroke
- Patented spring-loaded cam lock for smooth operation & durability – no clutch to wear out or lock to manually engage
- Toe straps accommodate large work boots
- Padded hand crank & brake lever for added comfort

## [2] ULTRA Work Bench (2004) ↘

- Used to transport tools & supplies up the scaffold
- Adjustable from 14" to 24"
- Raises and lowers with the jack
- Versatile, can be installed as needed at any time

## [3] ULTRA Pole Anchor (2008) ↘

- A mud sill in loose soil conditions (grass, dirt, clay & sand)
- Easily attaches to the bottom of ULTRA & ALL PRO Poles
- Uses stainless steel pins for connections
- Spiked anchor offers security on soft & uneven surfaces

## [4] ULTRA Pole Base (2009) ↘

- Easily attaches to ULTRA & ALL PRO Poles
- Non-skid base works well for flat & hard surfaces
- Included with 24' ULTRA & ALL PRO Poles

## [5] ULTRA/All Pro 6' Pole Connector (2013) ↘

- Can join any two pole lengths together, ULTRA or ALL PRO
- Allows 3' overlap in each section of the adjoining poles
- Spring-loaded stainless steel connector pins

## [6] ULTRA Brace (2002) ↘

- Used to secure aluminum poles to the work wall
- Full swivel head & nailing clips to cover all possible roof pitches
- Provides rigid, triangular bracing as required by OSHA