

Measuring Tape w/ Digital Display


user manual



AdirPro


www.adirpro.com





1. Battery drawer: pull out it to change the battery
2. Blade
3. Lock key: press it to pull out or retract the blade; release it to lock the blade
- 4~7. Function buttons

LCD display



' : Feet

" : Inch

cm : Centimeter

∞: Battery warning

↔: Outside measuring

→: Inside measuring (add case length)

H : In hold situation


M: Displayed data from memory


n: Sequence number of M

Function Buttons

Using buttons

First function: press shortly  (HOLD, , UNIT, )

Second function: press and hold >1s  (X→M, MR, C)

press shortly in hold ("H") situation  (X→M, MR)

HOLD

HOLD: Press shortly. Hold or free the measurement. In hold situation, "H" is displayed

↔↔|...X→M

↔↔: Press shortly. Change outside or inside measuring mode and reverse LCD figures orderly: outside measuring—inside measuring—outside measuring, LCD figures in opposite view—inside measuring, LCD in opposite view. Add case length of 7.6cm in inside measuring mode.

X→M: Press and hold 1S. Turn into "H" mode, save the measurement to memory, add 1 to the sequence number, display "H" "M" and sequence number. It can store 8 data. The 9th data will be stored to M8, the old sequence number 2~8 minus 1. The first data M1 will be covered.

Press shortly in "H" mode. Result is same as above

UNIT...MR

UNIT: Press shortly. Convert unit orderly: cm—ft and inch—inch—decimal inch





MR: Press and hold 1S. Turn into "H" situation, recall the data in memory, display "H" "M" and number
Press shortly in "H" situation. Result is same as above. Press again it will display next stored data, and add 1 to the sequence number

⏻...C

⏻: Press shortly. Power switch. Automatic shutoff after 6 minutes of inactivity



C: Press and hold 1S. Set zero in free mode

Clear the displayed data from memory in "H" mode



Warnings:

- ~ Do not retract the blade too fast ($<1.5\text{m/S}$) to avoid injury
- ~ Blade must be retracted fully when changing the battery
- ~ Change battery: display gets blurry or low battery icon displays
- ~ Do not pull the blade out completely
- ~ Do not use buttons while blade is moving
- ~ To clean the sensor, stick a $1.2 \times 2.5\text{cm}$ bi-sided piece of adhesive tape on the blade between the scale and the housing. Pull the blade back and forth several times. The tape will bring dirt out. Take off the tape after cleaning.

Error messages	Reasons	Corrective action
Display 	1. Voltage of battery has dropped 2. Suffered from strong interference	1. Replace the battery 2. Turn off the power and turn it on again
Display "F xxxx" and not accurate	Blade moves too fast	Move the blade smoothly (<1.5m/S)
Display  after change battery	Sensor is dirty	Use double sided tape cleaning method
Display "E---0"	Blade is not retracted fully	Retract the blade fully
Display "E---8"	Blade is pulled out too far	Retract the blade
Button and display are dead	Suffered from strong interference	Take out the battery and insert it again



AdirPro

AdirPro

Irvington, NJ 07111

customersupport@adircorp.com